



Cleaning and maintaining your ODS scanner



Cleaning and Care:

- Always use a soft microfiber cloth for cleaning
- Wash surfaces (book cradle, housing) with a soft, damp cloth as needed
- Clean camera lens with a dry microfiber cloth (do not use glass cleaner, water or rubbing alcohol)

-- NOTICE --

- Improper cleaning can destroy electronic and electrical components and can damage the appearance of the specific components and will void the warranty
 - Never clean the scanning system with a water jet
 - Do not use any aggressive or abrasive cleaning agents
 - Ensure that liquid does not penetrate the housing when cleaning
- Never use steel wool or other rough methods or agents to clean the device